

NATALIE BLAKE STUDIOS

802 254-9761 Brattleboro, Vermont info@natalieblake.com

Pod Installation Instructions Permanent Security Method with Adhesive

Materials Needed

Level

Fast Grab Loctite Glue

Caulk gun for the glue

Tool for spreading glue, such as a plastic knife

Non-marking tape for hanging template

Dropcloth and rags for adhesive application and clean up

Sharp blade (such as a box cutter/Exacto) for cutting the Tyvek

For larger pieces, we recommend at least two people work on this install to help level the template and to assist in the organization of the numbered pods.

Installation Process

1) Tack or tape template to the wall at desired placement. Use a level to check top and bottom edges. You may need to tape or tack various places in the template so that it sits even and flush, given the wrinkles that occur in shipping.

2) Each pod is numbered with the corresponding cut out on the template, organized in boxes.

3) Apply adhesive to the back of the pod and smooth out over the ENTIRE surface. You may need to dab a little more in the middle of the pod for better wall grab. Keep glue away from the edges.

4) Press the pod up to the wall in its designated spot on the template. Pull back to create mountains and valleys in the glue, press again and hold for 10-30 seconds.

5) When the piece complete, you can slowly remove the template.

6) Send questions to info@natalieblake.com and we should be able to respond quickly, or **call or text Natalie at 401 339-5444**. We love to see photos of installed pieces, please send them along when your piece is up!

Thank you for supporting our studio, Natalie and the Studio Team